


AMPTEK, INC.

14 DEANGELO DRIVE, BEDFORD, MA 01730-2204 U.S.A.
 TEL + 1 (781) 275 2242 FAX + 1 (781) 275 3470
 e-mail: sales@amptek.com WWW: http://www.amptek.com

Application Note: A111 Threshold Adjustment

A) Increasing the threshold of the A111:

Increasing the threshold of the A111 beyond the x10 provided by shorting out Pins 7 and 8 can be achieved by an RC feedback as shown below:



Apart from unit to unit variation, the discrimination levels will be as follows:

- 1) Shorting out Pins 7 and 8 will result in x10 increase of nominal threshold:

$$(5 \times 10^4 \text{ electrons} \times 10 = 5 \times 10^5 \text{ electrons.})$$

- 2) Shorting our Pins 7 and 8 plus feedback:

$$R = 50 \text{ K} \quad C = 2.2 \text{ pf} : \text{x17}$$

$$R = 20 \text{ K} \quad C = 3.3 \text{ pf} : \text{x23}$$

$$R = 5 \text{ K} \quad C = 4.7 \text{ pf} : \text{x40}$$

$$R = 2 \text{ K} \quad C = 6.8 \text{ pf} : \text{x88}$$

Intermediate values can be obtained by adjusting the value of R.

B) Decreasing the Threshold of the A111:

Decreasing the threshold of the A111 beyond the nominal 5×10^4 electrons can be achieved by adding a resistor from Pin 8 to Ground. A 300Ω resistor will approximately double the sensitivity resulting in a threshold of 2.5×10^4 electrons.