

AMPTEK, INC.

14 DEANGELO DRIVE, BEDFORD, MA 01730-2204 U.S.A.

TEL + 1 (781) 275 2242 FAX + 1 (781) 275 3470

e-mail: sales@amptek.com WWW: http://www.amptek.com

A225 APPLICATION NOTES


1. A225 Overload Characteristics

The A225 can be operated at high supply voltage ($V_s = +25$ VDC) in order to maximize the dynamic range and hence minimize the overload conditions. Furthermore, PIN 5 can be connected to a negative supply up to -2 VDC to further decrease the overload recovery time.

Up to 100 Mev (Si) or 500 picocoulomb can be analyzed with the A225 without overloading the unit, resulting into a dynamic range of 40,000.


The x10 overload characteristics of the A225 are: $<20 \mu s$ @ $V_s = +25$ VDC and $<40 \mu s$ @ $V_s = +5$ VDC.

2. Inverter for A225/A206 When Detector Signal is Positive



3. A225 Adjustable Sensitivity

The sensitivity of the A225 can be reduced by adding the following external network:



Example: $C = 10$ pF; $R = 300$ K Ω will reduce the sensitivity by a factor of 10.

R will have to be adjusted for the individual detector load so that no undershoot occurs on the output pulse.

Important: An equivalent detector load (typically 150 – 200 pF) must be present for PIN 1 to ground in order to stabilize the loop and reduce high frequency oscillation on the output pulse.